




OLIVIA

Assembly Instructions




Thank you for your purchase.

Unpack all content and check to ensure that all of the parts are in proper condition. To help protect the environment, use the appropriate recycling and discarding methods for the packaging items.

Read ALL assembly instructions before beginning. If you have any questions, please contact your installer or Salamander Designs at 800-535-5659.

Tool Required:

Philips Screwdriver




PARTS - Supplied with Armless, Left and Right-End Chairs

①




5/16 - 18 x 50 mm
Connector Bolt
Part# 012028

②



1/4 - 20 x 45 mm
Connector Bolt
Part# 002253

③



1/4 - 20 x 70 mm
Connector Bolt
Part# 003356


④



1/4 - 20
Hex Nut
Part# 005489


⑤

Spacers




⑥



Hex Wrench
Part# 005490



1 Attaching Back Rests




A. Remove four hand-tightened screws from the back rest frame.




B. Remove lower back removable panel.

Align the backrest screw holes to the upper and lower holes in the chair mechanism tongues.

Install and tighten screws.




2 Tactile Transducer - Optional



If you have purchased a Tactile Sound Transducer for your chair(s), install before connecting seats.

Remove lower back panel. Screw on jam nut included with transducer kit. Approximately 3/8" (10 mm) of threads should be exposed on bolt on chair frame. Screw transducer onto bolt to meet jam nut. Make sure transducer sits at least 1/8" (3 mm) above inner chair frame cross rail (adjust if necessary), tighten jam nut and transducer to lock in-place.


3 Power Seating - Optional



4 Connecting Seats to Arms (End Chair to Straight or Corner Section)


A. Align pieces in location, as they will be final assembled.

Align front and back bolt holes.




Spacer info:



- Spacers are needed when connecting seats to arms. Each side of a seat that does not have an arm needs a spacer.
- Spacers match the shape of the chair bases and are attached along the side of the base.



Example: In a configuration of 4 recliners 6 spacers are needed.




B. Extend foot rest to access front bolt holes and secure connection by inserting bolts (#1) through chair and into arm.




C. Remove lower back panels and locate the back bolt holes.

Secure connection by inserting bolt (#1) through chair and into arm.



5

Connecting Seat to Seat (Without Arms Between Seats) - Recliner to Recliner




A. Extend foot rest to access front bolt holes.

Insert two 1/4" (6 mm) spacer panels between chairs (align bolt holes).




Secure connection by inserting bolt (#2) through chair frames.

Align front and back bolt holes.

Fasten with nut (#4).




In this configuration 2 spacers are needed between each seat.



B. Remove lower back panel and locate the back bolt holes.

Secure connection by inserting bolt (#2) through chair frames.


Fasten with nut (#4).



2 spacers are needed between seats.

6

Connecting Seat to Seat (Without Arms Between Seats) - Recliner to Non-Reclining Unit






A. Extend foot rest on recliner, remove front panel on chair (pull outward to disengage hook & loop fasteners) to access front bolt holes.

Insert two 1/4" (6 mm) spacer panels between chairs (align bolt holes).

Secure connection by inserting bolt (#2) through chair frames.

Align front and back bolt holes.


Fasten with nut (#4).



B. Remove lower back panel and locate the back bolt holes.


Secure connection by inserting bolt (#2) through chair frames.

Fasten with nut (#4).



2 spacers are needed between seats.

7 Connecting Seat to Seat (Without Arms Between Seats) - Recliner to Chaise





A. Extend foot rest on recliner, remove seat on chaise (lift seat up to disengage hook & loop fasteners) to access front bolt holes.

Insert two ¼" (6 mm) spacer panels between chair and chaise (align bolt holes).

Secure connection by inserting bolt (#2) through chair frames.

Align front and back bolt holes.


Fasten with nut (#4).



B. Remove lower back panel and locate the back bolt holes.


Secure connection by inserting bolt (#2) through chair frames.

Fasten with nut (#4).



8

Connecting Seat to Seat (Without Arms Between Seats) - Recliner to Corner Seat





A. Extend foot rest on recliner to access front bolt holes.

Insert two ¼" (6 mm) spacer panels between chair and corner.

Align front and back holes.

Secure connection by inserting bolt (#2) through chair frames into pre-installed T-nut in corner.


Tighten.



B. Remove lower back panel on recliner and locate the back bolt holes.


Secure connection by inserting bolt (#3) through chair frames into pre-installed T-nut in corner.

Tighten.



9

Connecting Seat to Seat (Without Arms Between Seats) - Non-Reclining Unit to Non-Reclining Unit






A. Remove front panel on chair or seat on chaise to access front bolt holes.

Secure connection by inserting bolt (#3) through chair frames. (DO NOT use spacer panel supplied with recliner).

Align front and back bolt holes.

Fasten with nut (#4).




B. Remove lower back panel on recliner and locate the back bolt holes.

Secure connection by inserting bolt (#3) through chair frames.

Secure connection by inserting bolt through chair frames into pre-installed T-nut in corner.

Tighten.



Warranty:

For Salamander Seating Limited Warranty details:

<https://www.salamanderdesigns.com/customer-service/warranty/>

Leather care tips:

Leather is a natural product and variations in color can occur, along with minor flaws such as scars and other markings that give each hide its own unique character. The subtle markings on leather distinguish genuine leather from manmade materials.

We recommend that you look after your chair by not exposing it to direct sunlight or placing it too close to a heat source, such as a radiator, which will cause the leather to dry. To remove any dust and dirt we recommend vacuuming with a soft brush. To remove simple stains (water soluble), please use a soft cloth or sponge with a little water. For more professional care and to prolong the life of the leather, we recommend the products from Leather Master.

Fabric care tips:

Remove ballpoint pen, red wine, mustard, cola, tea, coffee, orange, and grape juice using mild liquid soap and lukewarm water. Rub soap foam in circular motion with sponge or soft brush. Pat area dry after cleaning. When completely dry, brush in the direction of the nap.

Powered Seating:

Power Mechanism Electrical Specifications: 110 V AC, 2.0 amps nominal load, 5.0 amps max load, thermally protected.

We recommend a small size power strip to connect multiple power chairs. It is also possible to utilize multiple Y-type splitters to connect chairs in series. Please note the specifications of the power components and be cautious not to overload the electrical circuit.



**SALAMANDER
DESIGNS**

Furniture Shaped By Your Needs ®

phone: 800-535-5659

www.SalamanderDesigns.com